



Fox Delta

Amateur Radio Projects & Kits

FD- GCPU - 0613

GCPU Parts List: PIC18F4550 General Purpose 128X64 Graphic LCD CPU

Graphic CPU – 0613 PCB Troubleshoot:

Check for +5V at following locations:

+Ve lead of: C1, C2, C7, C19, C20,

RFC6 Both ends

Remove PIC from Socket and check continuity of traces from PIC to LCD:

LCD PIN No.	PIC PIN No.
4	25
5	10
6	9
7	19
8	20
9	21
10	22
11	27
12	28
13	29
14	30
15	17
16	6

Check +5V at PIC PIN 11 and 32